
AIBO Recognition

for ERS-210 Series ERF-210AW06E [English Edition]

Quick Guide



Printed on recycled paper

Sony Corporation © 2002 Printed in Japan





Start! Before playing with AIBO, make sure you insert the battery pack and "Memory Stick" correctly.

Open the cover.

Grasp AIBO securely by the body, turn it upside down, and open the cover.



Press the Pause button.

If you press the Pause button located on AIBO's chest, the chest light lights green. After a while AIBO will begin to movel



Insert the "Memory Stick."

With the ▼ symbol pointing down and the label facing the direction of the battery slot insert the "Memory Stick" until you hear it click into



Place AIBO on the floor in this position.

Place AIBO on a non-slip even surface (such as short pile carpet) in this position.



Insert the battery pack.

Hold the battery pack with the connector facing downward, then insert it into the slot until you hear it click into place. and close the cover.



Charge AIBO.

Connect the conversion plug to the AC adapter, and charge AIBO. When charging is complete, remove the conversion plug from AIBO.



Modes and conditions of AIBO

With AIBO Recognition, AIBO can enter the following modes and conditions.

Pause mode



To turn AIBO off, press the Pause button located on its chest. Place AIBO in this mode before changing or replacing the battery or "Memory Stick."

When you press the pause button on AIBO's chest

- When you press the pause button on AIBO's chest.
- When AIBO has been active for an extended period

Active condition

The mode indicator goes off.

Autonomous mode

AIBO moves around on its own. AIBO acts on its own volition, based on its emotions, its instincts, and the information it collects through its

built-in camera, microphone, and sensors. The chest light

lights green.

Sometimes

dozes off!

AIRO

To wake up AIBO, touch or talk to it.

- · Do not place AIBO in any location where it might fall or be subjected to vibration, or on any unstable surface
- Do not place anything near AIBO that may hinder its movement.

- AIBO returns to the Station on its own.
- You place AIRO on the Station while it is operating
- AIBO moves from the Station on its
- You remove AIBO from the Station



AIBO takes a nap or even stays awake while charging.



The Energy Station ERA-210P1 is an optional accessory.

Pick up AIBO quickly.



An object is

caught in any

one of AIBO's

Press the

head sensor

for 3 seconds.

ioints

When two or more of AIBO's paw sensors are pressed, it thinks it has been placed on the floor and returns to Autonomous mode. AIBO may start walking after returning to Autonomous mode, so be careful not to touch any of its paw sensors when you hold it.

When AIBO is picked up, it moves

prevent AIBO from making

causing them to drop it in

person picking it up, possibly

into the Pick-up condition. This is to

movements that might surprise the



The mode indicator

lights

If an object becomes jammed in any one of AIBO's joints, AIBO goes limp, and all of its joints become loose. This condition prevents you from getting your fingers caught between AIBO's joints and injuring

Jam condition

Pick-up

condition

consequence.

.

From AIBO to you

Mode indicator

This light indicates AIBO's current mode.








Eye lights

AIBO's eye lights indicate its mood. The illustrations on the left are examples of AIBO's various moods.



Chest light


AIBO uses its chest light to indicate its physical condition.

Active (moving): lighted up green Charging: lighted up orange Charging irregularity: flashing orange Inactive (stopped): off



Chest light

AIBO charges on its own



Note

If AIBO is more than 70 cm from the pink ball on top of the marker stack, AIBO will not be able to find the Station.

If AIBO cannot find the Station, refer to page 26 of the User's Guide, and get AIBO to perform a marker color check.

Words apprehensible to AIBO

AIBO does not understand what you say when:

- While AIBO is emitting sounds or moving, it cannot hear you easily.
- AIBO may not recognize several words depending on its mode or condition.
- Even though AIBO understands you, it may choose not to respond or do as you say.
- AIBO cannot hear you if its surroundings are noisy. Call out to AIBO under quiet conditions.
- If you say a word whose pronunciation is unclear, AIBO cannot recognize it. Speak very clearly.

Calling AIBO's name

AIBO./Registered name (the name you gave AIBO)

AIBO reacts when it is called. Even after AIBO learns its own name, it reacts when you call it "AIBO."



Praising, scolding or encouraging AIBO

Good boy./Good girl./Good AIBO.

These words are for praising AIBO. They have the same effect as when you praise AIBO by pressing the head sensor.

Don't do it./Don't do that.

These words are for scolding AIBO. They have the same effect as when you scold AIBO by pressing the head sensor.


Go for it

These words are for encouraging AIBO.

Greetings

Good morning./Hello./Hi./Good night./ Bye bye./I'm here./Nice to meet you./Shake./ Shake hands.

Self-charge



Teaching AIBO

Name registration.

Give a name to AIBO (see page 34).

What's your name?

AIBO answers the name you gave to it in its own voice.

Owner registration.



What's your owner's name?

AIBO answers its owner's name (your name) in its own voice

Taking a picture

Take a picture.

AIBO takes a picture with its built-in camera. (page 41)

Moving

Come here./Over here./Sit down./Stand up./ Lay down./Go right./Turn right./Go left./ Turn left.

Answering AIBO

Yes./No.

These words are for answering questions asked by AIBO.

