


Filter Attachment for 3D Glasses

[TDG-BR250/BR200]

Instructions/Uputstvo

© 2011 Sony Corporation



Warning

When you attach this filter to your 3D glasses and watch 3D video images under some fluorescent or LED lighting, etc., flickering or flashing lights may be observed. This flickering or flashing may trigger epileptic seizures or blackouts (photosensitivity) in a very small percentage of individuals. If you observe such flickering or flashing, IMMEDIATELY stop watching the 3D video images.

Attaching the filter

- 1 Pinch the tab of the filter, and insert the filter in the space ① between the lens and the frame.
- 2 Insert the filter in the space ② between the lens and the frame.
- 3 Push the lower half of the filter to attach.
- 4 Peel off the tab while holding the filter.

Note

The filter is fragile. If the filter becomes dirty, wipe it with a cleaning cloth for glasses after removing any dust.

Srpski

Upozorenje

Kada na svoje 3D naočare stavite ovaj filter i gledate 3D video slike pod fluorescentnom ili LED rasvetom itd. možda ćete videti treptajuće svetlo ili bljeskanje. Navedeno bljeskanje ili treptajuće svetlo može izazvati epileptički napad ili zamračenje (fotoosetljivost) kod vrlo malog procenta osoba. Ako doživite treptajuće svetlo ili bljeskanje, SMESTA prestanite gledati 3D video slike.


Postavljanje filtera

- 1 Stisnite jezičak filtera i umetnite filter u prostor ① između sočiva i okvira.
- 2 Umetnite filter u prostor ② između sočiva i okvira.
- 3 Gurnite donju polovinu filtera da biste ga pričvrstili.
- 4 Skinite jezičak držeći filter.


Napomena

Filter je krhak. Ako se zaprlja, obrišite ga čistom krpom za naočare nakon uklanjanja prašine.


1



2



3



Predstavništvo Sony Europe Ltd.

Omladinskih Brigada 88a
11 070 Novi Beograd
Republika Srbija

Sony Info Centar
+381 11 228 33 00
www.sony.rs
support.rs@eu.sony.com